INSTALLATION INSTRUCTIONS




OUTLAW DROP NERF STEP BAR

APPLICATION:
TACOMA DOUBLE CAB 2024
PART NUMBER:
20-12785

CONTENT			
ITEM	QUANTITY	DESCRIPTION	TOOLS NEEDED
1	1	DRIVER STEP BAR	
2	1	PASSENGER STEP BAR	
3	1	DRIVER MOUNTING BRACKET "A"	
4	1	PASSENGER MOUNTING BRACKET "A"	
5	2	DRIVER MOUNTING BRACKET "B"	
6	2	PASSENGER MOUNTING BRACKET "B"	
7	12	M8 HEX HEAD CAP SCREW	
8	12	M8 SPLIT LOCK WASHER	
9	12	M8 FLAT WASHER	
10	12	M10 SERRATED FLANGE HEX HEAD BOLT	
11	12	M10 SERRATED FLANGE HEX NUT	


ANTI-SEIZE LUBRICANT MUST BE USED ON ALL STAINLESS STEEL FASTENERS TO PREVENT THREAD DAMAGE AND GALLING



PROCEDURE


Remove contents from box, verify if all parts listed are present and free from damage.
 Carefully read and understand all instructions before attempting installation.

 Failure to identify damage before installation could lead to a rejection of any claim.




ECO #:W23-0112

- 2. Locate the front mounting holes on the driver side of the vehicle and remove the factory bolts.
- 3. Loosely install Driver Mounting Bracket "A" (item 3) using the M8 hardware (items 7-9). See Figure 1.




- 4. Remove the factory hardware from the center and rear mounting holes.
- 5. Loosely install Driver Mount Brackets "B" (items 5) using the M8 hardware (items 7-9). See Figure 2.
- 6. Repeat **Steps 2-5** on the passenger side of the vehicle.



ECO #:W23-0112

- 7. Loosely attach the Step Bars (items 1 and 2) onto the mounting brackets using the M10 hardware (items 10 and 11). See Figure 3.
- 8. Align and adjust the step bars and brackets as needed.
- 8. Tighten and torque all M8 fasteners to 15-18 ft-lbs, and all M10 fasteners to 30-35 ft-lbs.




DATE: 7/2/2024



CARE INSTRUCTIONS

- REGULAR WAXING IS RECOMMENDED. DO NOT USE ANY TYPE OF POLISH OR WAX THAT MAY CONTAIN ABRASIVES.
- STAINLESS STEEL PRODUCTS CAN BE CLEANED WITH MILD SOAP AND WATER. STAINLESS STEEL POLISH SHOULD BE USED TO POLISH SMALL SCRATCHES.
- GLOSS BLACK FINISHES SHOULD BE CLEANED WITH MILD SOAP AND WATER.







WARNING



Failure to follow these instructions could lead to death, personal injury, and / or property damage.

Failure to follow these instructions could lead to death, personal injury, and / or property damage.

FASTENERS:

All Westin supplied fasteners must be utilized and installed in accordance with the installation instructions and apply torque to the specifications as defined. DOUBLE CHECK ALL FASTENERS BEFORE INITIAL USE, AND PERIODICALLY IN THE FUTURE TO ENSURE PROPER FUNCTION AND SAFETY.

DRILLING:

Most Westin products do not require drilling for installation. If drilling is defined as required, use caution when drilling a vehicle. FAILURE TO REVIEW AN AREA TO BE DRILLED MAY RESULT IN PERSONAL INJURY AND/OR INJURY TO OTHERS AS WELL AS VEHICLE DAMAGE.

EYE PROTECTION:

ALWAYS WEAR SAFETY GLASSES OR GOGGLES DURING THE INSTALLATION PROCESS TO AVOID PERSONAL INJURY.

MAXIMUM TOWING/CARRYING CAPACITY: (if applicable)

The Westin Receiver Hitches will have a visible tow rating label affixed directly on the product. User should never exceed the vehicle manufacturers maximum tow and weight rating regardless of the capacity of the hitch. FAILURE TO FOLLOW THESE GUIDELINES WILL VOID THE WESTIN WARRANTY AND MAY RESULT IN PERSONAL INJURY AND/OR INJURY TO OTHERS AS WELL AS VEHICLE DAMAGE.

FOR CALIFORNIA RESIDENTS ONLY-PROP 65 WARNING:

Some products may contain chemicals such as DEHP, which can cause cancer, birth defects or other reproductive harm. For more info go to www.p65warnings.ca.gov